



* Adjust voltage to be > Vcc before installing jumpers

TMD Innovations		
H-Clock		
Len Bayles	Rev 1.0 5/11/2010	PS Monitor